

W3012-W3612, W3015-W3615, W301224-W361224, W301524-W361524

W2418-W3618, W301824-W361824

W2412GD-W3612GD, W3015GD, W3615GD, W361524GD

W3018GD, W3618GD, W361824GD, W361224GD

ASSEMBLY INSTUCTIONS

Getting started:

prepare a protection layer, a screwdriver


STEP 1: Joint side panel with back panel

STEP 2: Joint side panel with back panel and attachching top panel for giving support

STEP 3: Joint back panel with side panel and back panel

STEP 4: Attach frame on

STEP 5: Fix door onto the frame and adjust the cover-space



PARTS LIST

NO.	Description	QTY
A	SIDE PANEL	2
B	BACK PANEL	1
C	TOP&BOTTOM PANEL	2
D	FACE FRAME	1
E	CABINETS DOOR	2

6	1 1/4" SOFTCLOSE HINGE	4	 1 1/4" hinge
5	3/4" ROUND HEAD SCREW	4	 3/4" round head screw
4	BUMPER	4	 Bumper
3	9/16"ROUND HEAD SCREW	56	 9/16" round head screw
2	CLEAT	14	 Cleat
1	1"FLAT HEAD SCREW FOR CARCASS	8	 1" flat head screw
NO.	Description	QTY	PICTURE

HARDWARE LIST

